F1
User Manual

Table of Contents

1. Security 5
2. Getting Started 7
2.1. Batteries 7
2.1.1. Installing and uninstalling the battery 7
2.1.2. Charging the battery 7
2.1.3. Using the battery 8
2.1.4. Battery level indicator 8
2.2. Connecting to the Network 8
2.2.1. SIM card 8
2.2.2. Installing and uninstalling the SIM card 8
2.2.3. Unlock the SIM card 9
2.2.4. Connecting to the network 9
2.3. Text Input Method 9
3. Messaging 9
3.1. Write message 10
3.2. Inbox 10
3.3. Drafts 11
3.4. Outbox 11
3.5. Sent Messages 11
3.6. Broadcast Messages 12
3.7. SMS settings 12
4. Phonebook 12
5. Call History 13
5.1. Call history 13
5.1.1. Call Timers 13
5.1.2. Text Msg. Counter 13
5.1.3. GPRS counter 13
6. Settings 13
6.1. Dual SIM settings 14
6.2. Phone settings 14
6.3. Call settings 14

6.3.1. Advance settings 14
6.4. Network settings 15
6.5. Security settings 15
6.5.1. SIM1 security 15
6.5.2. Phone security 15
6.5.3. Auto Keypad Lock 15
6.5.4. Privacy protection 16
6.5.5. Mobile tracker 16
6.6. Connectivity 16
6.7. Restore factory settings 16
7. Tools ..... Error! Bookmark not defined.
7.1. Bluetooth 16
7.2. Torch 16
7.3. Calendar 16
7.4. Alarm 17
7.5. World clock 17
7.6. Calculator 17
7.7. Currency converter 17
7.8. Stopwatch 17
8. Multimedia 18
8.1. Camera 18
8.2. Image Viewer 18
8.3. Video recorder 18
8.4. Video player 18
8.5. Audio Player 19
8.6. Sound Recorder 19
8.7. FM radio 19
9. User Profiles 19
10. File Manager 20
11. Audio player 20
12. Fun & Games 21
13. Services 21
13.1. QQ Apps Center 21
13.2. QQ Browser 21

13.2.1. Bookmark 21
13.2.2. Open 21
13.2.3. Tab 21
13.2.4. Tool 21
13.2.5. Navigation 21
13.2.6. Settings 21
13.2.7. Help 21
13.2.8. Exit 21
13.3. STK 21
14. Camera 22
15. Appendix**..... 22**
15.1. FAQ 22
15.2. Error Message 22
15.3. Care and maintenance 23
16. SAR VALUE..... 23

Phone Shortcuts

By default the Centre Navigation key shortcuts are set as below:

UP: Video player

Down: Alarm

Left : User profiles

Right: Add new contact

General Information

Thank you for selecting our F1 mobile phone. This user guide will provide you with the general information and operation instructions.

The package includes a chargeable battery, a charger and other accessories. Please refer to the Accessory section for details.

Note:

- Use only accessories approved by the phone manufacturer to ensure safety. Failing to comply with this will violate the terms and conditions of the warranty.

- If the contents and displays described in this user guide do not match the actual operation of the phone set, please use the display of the actual phone set. We reserved the rights to change the mechanisms of the phone without notice.
- This user guide is subject to change without notice.

1. Security

Emergency call

In any country, you can dial 112 (or other emergency call number) for emergency help.

Note:

- Based on the nature of cellular networking, the success of the emergency call cannot be guaranteed.

For your safety

- Switch off the phone in hospitals and aircraft. Obey any restrictions. Wireless devices can affect the medical treatment and cause interference in aircraft.
- Some medical devices such as hearing aids and pacemaker may be sensitive to external radio frequency emissions. Consult the device manufacturers or your doctor before using the phone around the medical devices.
- Pay special attention to the ring tone volume and vibration settings if you have a heart problem.
- In areas with potentially explosive atmosphere, such as gas stations, fuel or chemical transfer or storage facilities, obey all signs and instructions.
- You phone will emit radio frequency even in the standby mode. Turn off you phone when so instructed.
- Always obey all the local laws and regulations. Do not use your phone while driving. Use Hands-free operation, if available, and give full attention to driving and to the road. Pull off the road and park before making or answering a call if driving conditions so require.
- If your phone is lost or stolen, notify your service provider immediately to stop the SIM card from being used.
- When you contact your service provider, they will need your IMEI number. It is printed on the back of your phone set (you can find it when you remove your battery), or call *#06# to look up your IMEI number. Copy this number and save it for future need.
- To prevent your phone from misuse, lock your SIM card or phone, and change passwords when necessary.
- Do not remove the battery without turning off the phone. Failure to follow this instruction may result in data lost.
- When you leave your vehicle, take the phone with you or place it in the glove compartment to avoid theft.
- Keep the phone, battery or charger out of reach of children.

Notices for your phone use

- Do not keep the phone near magnetic cards and other object with magnetism. The phone's magnetism may clear the information stored on floppy disk, pre-paid phone card and credit card.
- Use the phone near land phone, television, radio and office automatic devices may cause interference and affect the function of the mobile phone.

- Keep the phone dry, all kinds of liquid can erode the electronic circuit.
- Keep the phone away from extreme temperatures.
- Keep the phone away from hot places where the temperature may exceed 60°C, such as the dash board, windowsill, near fire or a lighted cigarette.
- Do not paint the phone.
- Do not drop the phone or violently crush or shake the phone.
- Do not disassemble or modify your phone. This can damage the phone, cause leakage and break the internal circuit.
- Use only damp cloth or non-static cloth to clean your phone. Do not use alcohol, thinner, benzene or other chemicals or abrasive cleaner to clean your phone.
- The phone will become warm under normal use and while in battery charging.
- Do not leave the phone with battery uninstalled or with the battery empty for a long period of time. This may cause data loss.
- The metal parts of the phone may irritate your skin depending on your health condition.
- Do not put the phone in the back pocket. Sitting on it may damage the phone. Do not put the phone on the bottom of a bag. You may crush it.
- When the vibrate mode is on, place the phone carefully to avoid it being dropped from a height or being moved to a heat source due to the vibrating.

Notice for batteries use

- Do not disassemble or modify your batteries, otherwise it can cause leakage, over heat, fire or explosion.
- Disposing battery in a fire can cause fire or explosion. Old batteries should be returned to your dealer or be disposed according to local regulations. Do not dispose the battery as household waste.
- Do not short the circuit of the battery with wires, needles or other metal objects, or store the batteries with necklace or other metal objects, otherwise it can cause leakage, over heat, fire or explosion.
- There is a risk of blinding if the liquid of the batteries gets into your eyes. In case of this, do not rub your eyes, you should rinse your eyes well with fresh water and go to the hospital immediately.
- If the leaked liquid of the battery touches the skin, it can burn the skin. Please wash your skin with fresh water and go to the hospital immediately.
- Never put the battery in your month. The liquid of the battery can be toxic.
- Stop using the battery when you find it became hotter, and change color and shape abnormally during use, charging or storing.
- Keep the batteries dry.
- Do not use or store batteries near fire, heater and other place with high temperature, otherwise it can result in leakage, over heat, fire or explosion. Store the battery in a cool and ventilated place without direct sun light.
- Do not charge the battery for more than 24 hours.
- The battery can be charged and discharged for hundreds of times but it will eventually wear out. The battery life is shortened with each charging.
- When replacing the battery, use only the batteries approved by the phone manufacturer. Damage resulting from using un-authorized batteries will not be covered by warranty.

Traffic safety

- Do not use your phone when driving a vehicle. Give full attention to driving and to the road. Provided there is an emergency, stop your vehicle in a safe place

and then use your phone. Please obey all the local traffic laws and regulations.

- Normally the electronic systems in the vehicle should not be affected by the RF (Radio Frequency) signals from your wireless phone. However if you suspect any damage is resulting from the RF of your phone, contact your car dealer. Stop using your phone in the car until a qualified technician clears the problem.
- Turn off your phone when in the gas station or any place where using wireless equipment is prohibited. Do not place or transport your phone with inflammables or explosives, the internal sparkle may cause fire.

Airplane safety

- Power off your phone before boarding, the use of a wireless phone in an airplane will be dangerous to the operation of the airplane and disrupt the wireless telephone network and maybe illegal. Failure to observe these instructions may lead to law suit or denial of GSM cellular network service to the offender.
- Should there be an emergency situation, contact crew member.

2. Getting Started

2.1. Batteries

The battery is included in the package. It is not fully charged out of factory but it may still be able to power on your phone. Please completely use up the power of the battery and then charge it for at least 12 hours with your phone turned off. You battery will reach its optimal state after three cycles of charge and discharge.

2.1.1. Installing and uninstalling the battery

To install the battery, remove the back cover from the phone by pressing firmly on the cover and slide it down. Align the golden contacts of the battery to the contacts in the phone, and then gently snap down the battery into place. Re-assemble the back cover.

To uninstall the battery, flip the battery out from the bottom of the battery.

2.1.2. Charging the battery

Plug the charger into the socket on the side of your phone. Connect the charger to an AC wall socket. The blinking of the battery level icon indicates the battery is being charged. When the blinking stops, it indicates the charging is finished

During charging, the phone and charger will feel warm to the touch. This is normal.

Warning:

- The operating ambient temperature of the charger is 0°C-50°C. Do not use it when the temperature exceeds this limit.
- Use only chargers approved by the phone manufacturer to ensure safety. Failing to comply with this will violate the terms and conditions of the warranty.

2.1.3. Using the battery

The waiting time and calling time capacities specified by the phone manufacturer are obtained under the ideal operating environment. The actual values will vary with the network condition, operating environment and operation method.

Please comply with the local regulations of disposing the battery (such as recycling). Do not dispose it as household waste.

2.1.4. Battery level indicator

When the phone is on, the battery level indicator is located at the upper right corner of the screen.

2.2. Connecting to the Network

2.2.1. SIM card

Please insert available Subscriber Identity Module (SIM) card into your phone before using it. SIM card is supplied by your network carrier.

All the information related to network connection is recorded on the SIM card, so are the contact information such as names, phone numbers and SMS that you set to store on the SIM. You can take out the SIM card from the phone and insert it into another GSM phone to use it. Most new phones will recognize the SIM card automatically.

Do not touch the golden contacts of the SIM card and place it away from electricity and magnetism to avoid damage. You will not be able to use the phone if the SIM card is damaged.

Note:

- Before inserting and taking out the SIM card, always make sure that the phone is switched off and disconnected from any external power source; otherwise both the phone and the SIM card may be damaged.

2.2.2. Installing and uninstalling the SIM card

The SIM card usually comes attached to a special card. The metal contacts of SIM card is easily damaged by scratching, so take it out carefully before assembling it into the phone.

Switch off the phone; remove the back cover, battery and other external power source. Fit the SIM card into the SIM card slot. Align the angled corner of the SIM

card with the slot. Slide in the SIM card, make sure it is in place, install the battery, and restore the back cover.

Likewise, to remove the SIM card, switch off the phone, remove the battery and then take out the SIM card.

2.2.3. Unlock the SIM card

PIN code

Your Personal Identification Number (PIN) code protects the SIM card against unauthorized use. Your PIN code is usually supplied with the SIM card. If this security function is enabled, you need to enter the PIN code every time you turn on the phone. You can also disable this function.

To unlock the SIM card, press and hold the power button to turn on the phone. Enter the PIN code. After three consecutive incorrect PIN code entries, the code is blocked, and you need the PUK code to unblock it.

PUK code

This code is required to change a locked PIN code. If the code is not supplied with the SIM card, contact your service provider. After ten consecutive incorrect PUK code entries, the SIM card cannot be used any more. Please contact your service provider to buy a new SIM card. You cannot edit PUK code. If it is lost, Please contact your service provider.

2.2.4. Connecting to the network

After the SIM card is unlocked, you phone will automatically search for the registered network or other local available network. Once connected, the name of the network carrier will appear on the top of the screen.

You phone is now in Standby mode, ready for making and receiving calls.

2.3. Text Input Method

This phone provides various text input methods that allow you to use less key strokes to input and search for text:

- ABC/abc input method
- Hindu input method
- Numbers 123 input

3. Messaging

You can send and receive the SMS as well as use Cell Location Display with this function.
This chapter introduces the message services provided by the GSM network. Some services may not be supported by the local network.

3.1. Write message

- **Send to:** Input number and then send SMS to the input number.
- **Input method:** Change the input method.
- **Advanced:** Insert pictures, melody, phone number and bookmark.
  - **Insert Number:** Insert the number of the contacts.
  - **Insert Name:** Insert the phone book name.
- **Save to Draft:** Save the SMS in the Draft box.

Select [send to] to enter in the sending window after finishing the creation of the SMS. Select [Enter number] or [Add from phonebook] to search a phone number of the receiver and finally press **Left Soft Key**:

- **Send:** Send the SMS to sender
- **Edit Recipient:** Edit the recipient number.
- **Remove Recipient:** Delete the selected recipient.
- **Remove All Recipients:** Delete all recipients.
- **Save to Draft:** Save the SMS in the Draft box.

Press **OK Key** to send the SMS.

3.2. Inbox

The Inbox lists the received SMS and MMS.

You can view the received SMS with this function. Select an entry of SMS and press <Option> under the inbox SMS list window to perform:

- **View:** View the selected message.
- **Reply:** Reply the SMS to the sender;
- **Call sender:** Call the sender of the selected message.
- **Forward:** Forward the SMS to other via SIM card 1/ 2;
- **Delete:** Delete the selected entry of the message;
- **Delete all:** Delete all messages
- **Sort by :** Sort the sender、subject、unread/read、message size.
- **Filter by :** filter SIM1、SIM2、all messages.
- **Mark Several:** Delete the marked messages at the same time.
- **Advanced:** Press **OK Key** under this window to perform:
  - **Copy to phone:** current information copy to the phone.
  - **Copy to SIM1/2:** current information copy to the SIM1/2.
  - **Move to phone:** current information to move to the phone.
  - **Move to SIM1/2:** current information to move to the SIM1/2..

- **Copy All:** Between the phone and SIM card copy.
- **Move All:** Between the phone and SIM card move.

3.3. Drafts

Saved messages and unsent message are saved here.
Press **OK Key** to enter SIM1 drafts. And press **Left Soft Key** under the Drafts list window to perform:

- **View:** View the selected message.
- **Send:** Send the selected message.
- **Edit:** Edit the selected message.
- **Delete:** Delete the selected entry of the message;
- **Delete All:** Delete all messages
- **Sort by :** Sort the recipient、subject、message size
- **Mark several:** Mark several messages to delete at the same time.
- **Advanced:** Press [OK] under this window to perform:
  - **Copy to phone:** current information copy to the phone.
  - **Copy to SIM1/2:** current information copy to the SIM1/2.
  - **Move to phone:** current information to move to the phone.
  - **Move to SIM1/2:** current information to move to the SIM1/2..
  - **Copy All:** Between the phone and SIM card copy.
  - **Move All:** Between the phone and SIM card move.

3.4. Outbox

The out-going messages are listed here.

3.5. Sent Messages

Sent messages are saved here. Your options include:

- **View:** View the selected message.
- **Forward:** Forward the SMS to other via SIM card 1/ 2;
- **Delete:** Delete the selected entry of the message;
- **Delete all:** Delete all messages
- **Sort by :** Sort the recipient、subject、message size
- **Mark several:** Mark several messages to delete at the same time.
- **Advanced:**
  - **Copy to phone:** current information copy to the phone.
  - **Copy to SIM1/2:** current information copy to the SIM1/2.
  - **Move to phone:** current information to move to the phone.

- **Move to SIM1/2:** current information to move to the SIM1/2..
- **Copy All:** Between the phone and SIM card copy.
- **Move All:** Between the phone and SIM card move.

3.6. Broadcast Messages

Look up the broadcast messages. Your options include:

- **Receive Mode:** Turn on or turn off cell broadcasting.
- **Channels settings:** You can add, edit channel and can delete the current channel and cancel the read.
- **Languages:** set the cell broadcast language.
- **Read Messages:** Save read cell broadcast information.

3.7. SMS settings

Select the Text message card (SIM1) SMS settings, enter the setup menu, you can do the following:

- **Memory status:** View the quantity of MMS saved in the phone memories.
- **Save sent message :** Select to keep sending SMS on/off.
- **Preferred storage:** Select to save the MMS in phone or memory card.

4. Phonebook

You can save a phone number in the memories of SIM cards or phone.
Press **RSK Key** under the standby mode and then select Phonebook if you desire to enter in the function.
Select a contact in the contact list window and press **OK Key** to perform:

- **View:** Display the current number.
- **Send text message:** Directly input the SMS and send it to the searched phone number.
- **Call:** Call the current contact.
- **Edit:** Edit the current contact.
- **Delete:** Delete the current contact.
- **Copy:** Copy the current contact.
- **Send business card :** Through the SMS, MMS, Bluetooth to send VCard.
- **Add to Blacklist :** Will the current contact added to the blacklist list.
- **Mark several:** Mark the contact, and then send SMS or delete marked.
- **Caller groups :** In order to facilitate the address book managements，you can contact will be added to the different groups respectively. Can set for each group alone group the bell
- **Phonebook settings :** You can manage the phonebook with this function.
  - Preferred storage: You can select preferred storage in SIM1, SIM2, phone or all.

- Speed dial: You can assign the quick dial numbers (2-9) to the 8 frequently-used phone numbers.
- Extra number：You can choose the Fixed、Barred dial and service numbers、SOS number。
- Memory status: View the quantity of phone saved in the SIM cards or phone memories.
- Copy Contacts: Copy contacts between phone and SIM card.
- Move Contacts: Move contacts between phone and SIM card.
- Delete All Contacts: Such as the title.
- Backup contacts：You can back up the phonebook numbers in this function;

5. Call History

With this function, you can view the information of Call History、Call settings、Funny Accent Switch、Funny Accent Settings.

Press **OK Key** and select Call Logs under the standby mode if you are desired to enter in this function.

5.1. Call history

In the call history, you can carry out the following operations: view the call history, edit the call history, save the call history to phonebook, add the call history to the blacklist, delete the call history, you can also view the call time and call cost.

Select any a log, Press **Left Soft Key** to enter the Option list:

- **View:** View the detail of the current call.
- **Call:** Call the current number.
- **Send text message:** Directly input the SMS and send it to the current number.
- **Save To Phonebook:** save to phonebook.
- **Add To Blacklist:** Add the number to black list and block the same number to call you.
- **Edit Before Call：**Call to edit the number before the call record contacts.
- **Delete:** Delete the current logs.

5.1.1. Call Timers

Record all the talk time.

5.1.2. Text Msg. Counter

SMS reception count.

5.1.3. GPRS counter

GPRS traffic statistics.

6. Settings

You can set up various functions for the phone with this function.

6.1. Dual SIM settings

You can set up two SIM cards with this function.

6.2. Phone settings

You can customize your favorite phone functions based on your interest with this function.

- **Time and Date:** You can set home city, set time and date, set format for your phone.
- **Language :** Set the current system language.
- **Pref. input method:** Select the default input method.
- **Display**
  - **Wallpaper:** Select your favorite picture as the wallpaper of the standby window.
  - **Screen Saver :** Select waiting time and picture for the screen protection. You can open or close this function.
  - **Power on display** : Select your favorite picture as the Power on display of the window.
  - **Power of display :** Select your favorite picture as the Power of display of the window.
  - **Show date and time:** On or off display time.
- **Shortcuts :** You can set the direction key designated menu.
- **Dedicated Key:** You can set the direction key designated menu.
- **Flight mode :** You can set up two SIM card flight mode.
- **Misc. Settings**
  - **LCD Backlight:** here are set LCD brightness and time.

6.3. Call settings

- **Caller ID:** Need the support of operators.
- **Call waiting:** The network will inform you for a newly incoming call during the call. Please contact with your network operator to launch or close the function because the function requires the network support.
- **Call divert:** Divert an incoming call to a designated phone number under the presetting condition. This function can be launched or closed.
- **Call barring:** Set up the right of calling and answering. This function requires the network support. You can launch or close the function.
- **Line switching:** Switch the line between line 1 and line 2.

6.3.1. Advance settings

- **Blacklist:** blacklist open the blacklist contact could not be called a native.
- **Auto redial:** Set up whether the phone is tempted to redial when the call fails in connection.
- **Call time reminder:** Select to release prompt tone during the call in each integral minute time.
- **Auto Call Record :** Open automatically replay, dial-up connection failed to automatically replay.

- **Reject by SMS :** Turn on or turn off this feature.
- **Answer mode:** You can select Any key or Auto answer when headset mode.

6.4. Network settings

You can set up the phone network with this function.

SIM1/SIM2 network settings

- **Network selection:** choice the modes of searching the phone network, including Auto and Manual modes.
- **GPRS transfer pref.** : Select GPRS priority.

6.5. Security settings

You can manage your phone safely with this function.

The phone lock password, SIM card password and PIN2 support 4-8digit numbers, do not support other characters. The original password of the phone when leaving the factory is 1122. The password and PIN2 and SIM card are provided by the network operator. When the PIN/PIN2 is input wrongly in successively three times, the SIM card will be locked.

The PUK /PUK2 are required to input if you want to unlock the SIM card. The PUK/PUK2 is provided by the network operator. If the PUK is input wrongly in successively 10 times, the SIM card will be locked and discarded permanently.

6.5.1. SIM1 security

- **PIN lock:** open or close the PIN lock function. When PIN lock is launched, the PIN shall be input upon each power-on.
- **Change PIN:** PIN lock must be enabled, Just can be change.
- **Change PIN2:** input the correct PIN 2. Just can be change.

The SIM2 security setup is same to the SIM1 security setup.

6.5.2. Phone security

- **Phone lock**

Open or close the phone lock function. When the phone lock is launched, the phone lock password shall be input upon each power-on.

- **Change password**

You can change the phone password.

6.5.3. Auto Keypad Lock

Set to lock the keypad.

6.5.4. Privacy protection

Input the correct password into the interface of Data security in first.

- **Setting:** Set the modules of the privacy protection. These modules include Contacts, Messages, Call history, Image viewer, Video player, File manager, Keypad lock, etc.

If you select this modules for Data security, you must input the correct password when you want to view this modules .

6.5.5. Mobile tracker

You can track your phone when the phone lost;

6.6. Connectivity

- **Data account** : GPRS parameters add and set.

6.7. Restore factory settings

You can recover the phone into the initial setting with this function.

7. Tools

7.1. Bluetooth

Your options include:

- **Power:** Open or close the Bluetooth
- **Visibility:** Open or close the visibility.
- **My device:** Show the device which is connected
- **Search audio device:** Search for the audio device.
- **My name:** Show off the name of Bluetooth.
- **Advanced:** set up Audio path, Sharing permission and view the address of Bluetooth.
  - **Audio path:** You can select leave in phone or forward to Bluetooth headset.
  - **My address:** View Bluetooth address.

7.2. Torch

Turn on or turn off the torch here.

7.3. Calendar

The screen will highlight the date of today after displays the monthly calendar when you enter in the calendar function.
Press **Left Key** or **Right Key** to move by day.
Press **up Key** or **Down Key** to move by week.

Options will include

- Jump to Date: Jump to the date you wish for.
- Go to today: Return to the present day
- Go to weekly view: View the calendar by week.
- Panchangam: See the basic Indian days as per the Indian panchang as Day,Tithi,Paksha, Month,Yearl.
- Festival list: See the yearly festival list
- Settings: Set English or India calendar.
- Help: A brief description of India calendar.

7.4. Alarm

You can set up that the alarm clock will ring at a specific time with this function.

Setup of Alarm Clock

Set up the alarm clock with the following options:

- Set the alarm clock status as opened or closed.
- Set the alarm clock time.
- Set the repeat, once, Everyday, Days.
- Select alarm tone.
- Select the snooze time.
- Set the Alert type.

After setting please save the change.

7.5. World clock

You can view the current local time of various countries.

7.6. Calculator

You can conduct the basic arithmetic operations with this function.

- Input the first number.
- Press one of directional keys to select the arithmetic operation sign.

Input the second number.

7.7. Currency converter

Selection by the currency conversion.

7.8. Stopwatch

To use the stopwatch function including typical and nway stopwatch.

8. Multimedia

8.1. Camera

-

8.2. Image Viewer

You can view the photos snapped with the camera through this function.
Select a photo file and press **<Option>** under the photo list window

- **View:** View the selected image.
- **Details:** Show some information of image.
- **Browse Style:** You can select list style or matrix style.
- **Send:** Send the selected image to MMS or Bluetooth.
- **Use as:** Send the selected image file to the wallpaper, to screen saver or to phonebook.
- **Rename:** Change the name of the image.
- **Delete:** Delete the selected image.
- **Storage:** Select the photos storage.

8.3. Video recorder

In video recorder, your options include:

- **Switch to camera :** Switch to the camera interface.
- **Camcorder Settings:** Set up the video recorder.
- **Video Settings:** Set up the video parameters.

8.4. Video player

You can play the video with this function. Select a video and press [OK] Key under the video list window and begin to play. You can use the following keys during the play.

Key	Function
Left key	Press to go backwards. Press and hold to continuously go backwards.
Right key	Press to go forwards. Press and hold to continuously go forwards.
OK Key	Press to play/pause the video.
Left soft key	Press to go to Options.
Right soft key	Press to stop the video and go back
UP key	Press to enter/exit full screen.
Down key	Press to stop playing.

8.5. Audio Player

8.6. Sound Recorder

You can take a recorder in this function.

After record, access Options:

- **New record:** Select this option to record the sound.
- **Play:** Play the selected sound.
- **Append:** Continuously record after the previous record file and append it after the record file.
- **Rename:** Rename the selected sound.
- **Delete:** Delete the selected sound.
- **List:** View the currently-selected sound files.
- **Settings:** Entering this option you can set audio quality.
- **Use as:** Set as SIM1/SIM2 user profiles.
- **Send:** Send sound file to Bluetooth.

8.7. FM radio

You can choose to radYour options include:

- **Channel List:** Play, edit or delete the saved channels.
- **Manual Input:** Manually input the channel to search.
- **Auto Search:** Automatically search the channel.
- **Settings:** Set up to receive the FM broadcast at the backstage or receive the FM broadcast with the speaker as well as set up the record format and voice quality.
- **Record:** Record the currently-hearing FM.
- **File List:** List all recorded files.

9. User Profiles

Enter in the function; display the profile mode list including **General, Silent, Meeting, Outdoor, Earphone**.

Select one mode (Silent mode cannot be modified) and enter the option menu:

- **Activate:** Activate the profile mode.
- **Customize:** Customize the profile mode as following:
  - **Alert Type:** Set the alert type such as Ring only、Vib only, Vib. And ring, Vib. Then ring.
  - **Ring Type:** Set the ring type such as Repeat、Ascending、Beep once.
  - **SIM1/2 Incoming Call:** Set the ringtone for the SIM1/2 incoming call. You can also select ringtone from T card.
  - **Ringtone Volume:** Set the ringtone volume of the incoming call.

- **SIM1/2 message:** Select the ringtone for the SIM1/2 message. You can also select the ringtone from T card.
- **Message Volume:** Set the volume for message ringtone.
- **Keypad:** Select the ringtone for keypad.
- **Keytone Volume:** Set the volume for the keypad.
- **Power On:** Select the ringtone for the power on.
- **Power Off:** Select the ringtone for the power on.
- **System Alert:** On /off the system alert.

➢ **Reset:** Reset the setting to the default.

After plugging in the headset, ringtone will output from the headset as well as the phone, when there is incoming call or message.

10. File Manager

The File Manager lists the all the files stored in your memory card.

11. Audio player

You can enjoy the music with this function. You can use the following keys during the play.

Key	Function
Left Key	Press to switch to a previous song with cursor. Press and hold: go backwards
Right Key	Press to switch to a next song with cursor. Press and hold: go forwards
UP Key	press to the change music playback modes.
Down Key	press to the change music broadcast order.

Press **Left Soft Key** to view Play list, Your options include:

➢ **Play:** Play the currently-selected song.

➢ **Details:** View the detailed information of the currently-selected song.

➢ **Refresh list:** Refresh the list of current list

➢ **Settings:** Set up the music player.

- **List auto gen.**: set up to on/off the function.
- **Repeat:** Set up to open/close the function. If you open the function, you can select repeat Once or repeat All.
- **Shuffle:** Set up to open/close the function.
- **Background play:** Set up to open/close the function.

12. Fun & Games

The phone's built- F1 Race.

13. Services

With this function, you can perform the network-based service.

13.1. QQ Apps Center

- **More Apps**
- **One Browser**

13.2. QQ Browser

13.2.1. Bookmark

Open bookmark or Add bookmark

13.2.2. Open

Home page, Search, URL or History

13.2.3. Tab

Open in new tab, Create new tab, Left Switch, Right Switch, Close Current, Close All.

13.2.4. Tool

Save picture, View the whole picture, Free copy, Clear history, Download Manager, Copy, Paste, Account list.

13.2.5. Navigation

Forward, Refresh, Page up, Page down, Top ,Bottom.

13.2.6. Settings

Themes, Link underline, No-image mode, Prefetch page, Cookies, Search engine, Account list.

13.2.7. Help

Feedback, Help, About.

13.2.8. Exit

Exit the browser.

13.3. STK

SIM Card support is required in this service.

14. Camera

With this function, you can snap. Press **OK Key** to snap under the view-finding window.

Enter Camera Option, Your options include:

- **Switch to video recorder :** Switch to video interface.
- **Photos:** Enter in the album folder.
- **Camera Settings:** Set up the camera.
- **Image Settings:** Set up the photo parameters.
- **White Balance:** Adjust the color balance of the photo.
- **Scene Mode:** Set up the scene mode.
- **Restore Default:** Recover all settings into the initial values.

15. Appendix

15.1. FAQ

The phone cannot be turned on

When the battery is very low, the phone may not be turned on properly. Please charge the battery.

Cannot make certain calls

Check if Call Barring is set. If it is set, you may not be able to make calls or only certain calls are allowed.

My call is picked up by another phone

Check if call divert is set. If it is set, your incoming calls may be diverted to other numbers or devices.

15.2. Error Message

Please insert SIM card

Make sure you have inserted SIM card. If you have installed it but it cannot be detected, please try clean the golden contacts of the SIM card by using a dry cloth. If it still is not working, please contact your network carrier.

No service

If you are in an area not covered by your network, or if a physical obstacle is present, such as in an enclosed area, the message “No service” will be displayed on your Standby screen and you will not be able to make or receive calls. You can try move closer to a window for better reception.

For emergency only

When you are outside your network but inside other network, you can only make emergency call.

No Valid SIM card

Your SIM card is locked or it has an error. Please insert the right SIM card or contact your service provider.

Enter PUK code

After three consecutive incorrect PIN code entries, the code is blocked, and you need the PUK code to unblock it. Contact your service provider. After seven consecutive incorrect PUK code entries, the SIM card cannot be used any more. Please contact your service provider to buy a new SIM card.

15.3. Care and maintenance

Thank you for choosing our phone. Should you encounter any problem with the phone, please contact our dealer or qualified service provider.

Your phone is a finely designed and crafted product. Please use it with care. The following instructions will help you comply with the terms of the warranty and enjoy this product for many years:

- Keep the phone and all its parts and accessories out of the reach of children.
- Keep the phone dry, all kinds of liquid will erode the electronic circuit.
- Do not use or store the phone in a dusty place to avoid damaging the removable parts.
- Keep the phone away from hot places, high temperature can shorten the life of electronic device, warp or melt certain plastic and damage batteries.
- Do not attempt to open or disassemble the phone, non-expert handling may damage it.
- Do not drop, crush or shake the phone to avoid damaging the internal circuit board.
- Do not use harsh chemicals, cleaning solvents or strong detergent to clean the phone.
- Do not paint the phone or the paint may obstruct the removable parts and affect operation.
- Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone Do not hold the external antenna when the phone is in use. Holding the external antenna affects call quality and may cause the phone to operate at a higher power level than needed. In addition, use of unauthorized antennas may result in non-compliance with the local regulatory requirements in your country.

The above instructions apply to your phone, battery, charger and other accessories. If any of them does not work properly, please send it to a qualified service provider.

16. SAR VALUE:

GSM 900 Head 0.937 Body 0.891

GSM 1800 Head 0.832 Body 0.621